

NO SPIKE INSTALLATION INSTRUCTIONS

Lens Module Installation			
Diffuser Installation			
Asymmetrical Snoot Installation			

OUTDOOR SPIKE LIGHT

E571

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Lamp Type:** LED | 5W | 2700K | CRi 90
- **Material:** Aluminium
- **Ingress Protection:** IP65 Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS


! Electrical products can cause death, injury, or property damage. Maintenance and installation should only be carried out by a professional electrician.

- Ensure the main supply is switched off.
- Follow the instructions step by step.
- Connect the positive and negative ground wires, and connect the power cord.
- Fix the waterproof connector IP68 in the correct usage for tight connection.
- Add the accessories (lenses, color filters, honeycomb, asymmetrical snoot).
- Making sure all connections are tight.
- Reconnect power.

WARNING

! Make sure that the products are installed properly before connecting to electricity. Do not cover the luminaire. Do not exceed the maximum wattage rating of the lamp. If the light source is contained in this luminaire (integrated LED), it shall only be replaced by the manufacturer, his service agent, or a similarly qualified person.





SPIKE INSTALLATION INSTRUCTIONS

Lens Module Installation	1 	2 	3
	4 	5 	6
	Diffuser Installation		
	Asymmetrical Snoot Installation		

OUTDOOR SPIKE LIGHT

E571

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Lamp Type:** LED | 5W | 2700K | CRi 90
- **Material:** Aluminium
- **Ingress Protection:** IP65 Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS


! Electrical products can cause death, injury, or property damage. Maintenance and installation should only be carried out by a professional electrician.

- Ensure the main supply is switched off.
- Follow the instructions step by step.
- Connect the positive and negative ground wires, and connect the power cord.
- Fix the waterproof connector IP68 in the correct usage for tight connection.
- Add the accessories (lenses, color filters, honeycomb, asymmetrical snoot).
- Making sure all connections are tight.
- Reconnect power.


WARNING

! Make sure that the products are installed properly before connecting to electricity. Do not cover the luminaire. Do not exceed the maximum wattage rating of the lamp. If the light source is contained in this luminaire (integrated LED), it shall only be replaced by the manufacturer, his service agent, or a similarly qualified person.





EXTENSION TUBE SPIKE INSTALLATION INSTRUCTIONS



OUTDOOR SPIKE LIGHT

E571

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Lamp Type:** LED | 5W | 2700K | CRi 90
- **Material:** Aluminium
- **Ingress Protection:** IP65 Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS


! Electrical products can cause death, injury, or property damage. Maintenance and installation should only be carried out by a professional electrician.

- Ensure the main supply is switched off.
- Follow the instructions step by step.
- Connect the positive and negative ground wires, and connect the power cord.
- Fix the waterproof connector IP68 in the correct usage for tight connection.
- Add the accessories (lenses, color filters, honeycomb, asymmetrical snoot).
- Making sure all connections are tight.
- Reconnect power.


WARNING

! Make sure that the products are installed properly before connecting to electricity. Do not cover the luminaire. Do not exceed the maximum wattage rating of the lamp. If the light source is contained in this luminaire (integrated LED), it shall only be replaced by the manufacturer, his service agent, or a similarly qualified person.





MOUNTING BASE INSTALLATION INSTRUCTIONS



OUTDOOR SPIKE LIGHT

E571

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Lamp Type:** LED | 5W | 2700K | CRi 90
- **Material:** Aluminium
- **Ingress Protection:** IP65 Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS


! Electrical products can cause death, injury, or property damage. Maintenance and installation should only be carried out by a professional electrician.

- Ensure the main supply is switched off.
- Follow the instructions step by step.
- Connect the positive and negative ground wires, and connect the power cord.
- Fix the waterproof connector IP68 in the correct usage for tight connection.
- Add the accessories (lenses, color filters, honeycomb, asymmetrical snout).
- Making sure all connections are tight.
- Reconnect power.

WARNING

! Make sure that the products are installed properly before connecting to electricity. Do not cover the luminaire. Do not exceed the maximum wattage rating of the lamp. If the light source is contained in this luminaire (integrated LED), it shall only be replaced by the manufacturer, his service agent, or a similarly qualified person.





TREE MOUNTING BELT INSTALLATION INSTRUCTIONS

	1	2	3
Lens Module Installation			
Diffuser Installation			
Asymmetrical Snoot Installation			

OUTDOOR SPIKE LIGHT

E571

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Lamp Type:** LED | 5W | 2700K | CRI 90
- **Material:** Aluminium
- **Ingress Protection:** IP65 Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS

! Electrical products can cause death, injury, or property damage. Maintenance and installation should only be carried out by a professional electrician.

- Ensure the main supply is switched off.
- Follow the instructions step by step.
- Connect the positive and negative ground wires, and connect the power cord.
- Fix the waterproof connector IP68 in the correct usage for tight connection.
- Add the accessories (lenses, color filters, honeycomb, asymmetrical snoot).
- Making sure all connections are tight.
- Reconnect power.

WARNING

! Make sure that the products are installed properly before connecting to electricity. Do not cover the luminaire. Do not exceed the maximum wattage rating of the lamp. If the light source is contained in this luminaire (integrated LED), it shall only be replaced by the manufacturer, his service agent, or a similarly qualified person.

