


Connecting the Terminal Block

Connect main supply (brown - Live, blue - Neutral) into terminal block making sure all connections are tight.



OUTDOOR SPIKE LIGHT

E280

Please read instructions before commencing installation and retain for future reference.

SPECIFICATIONS

- **Material:** Aluminum-Opal PC Diffuser
- **Lamp type:** LED 15W | 3000K | 1550Lm
- **Ingress Protection:** IP65. Protection against entry of solid objects greater than 12mm in diameter.

INSTALLATION INSTRUCTIONS

! Electrical products can cause death, injury, or damage to property. Maintenance and installation should only be carried out by a professional electrician.

- Ensure main supply is switched off.
- Carefully remove the product from its packaging and screw the spike (1).
- Connect main supply wires to terminal block (2) making sure all connections are tight.
- Fix the fitting of light into the spike (3).
- Place the light to the ground with the spike (4)
- Reconnect power.

WARNING

- Make sure that the products is installed properly before connecting to electricity.
- Do not cover the fitting.

