





USE AND CARE GUIDE

Ø52cm | METAL - ACRYLIC - ABS - HEMP ROPE


CEILING FAN WITH LIGHT




SAFETY INSTRUCTION

READ THESE INSTRUCTIONS CAREFULLY AND KEEP THEM FOR FUTURE CONSULTATION.
WARNING: TO REDUCE THE POSSIBLE RISK OF FIRE, ELECTRICAL DISCHARGES OR PERSONAL INJURY, TAKE THE FOLLOWING INTO ACCOUNT:

1. Proceed with care. Read the instructions in full before starting the installation.
2. WARNING! This fan can only be used with a bipolar switch with a contact opening of 3mm.
3. The installation process must only be carried out by an authorized electrician.
4. The installation height, i.e. the distance between the blades and the floor, should be at least 2.3 meters.
5. Make sure there are no obstacles within the area of rotation.
6. Make sure the fan is securely attached to the ceiling.
7. WARNING! Do not use a switch with a voltage regulator to control the speed of the fan.
8. WARNING! To avoid damage, make sure that the blades are not bent over and that there are no foreign objects within the area of rotation.
9. WARNING! If the fan is installed close to the ceiling, the ceiling may not be lowered using rails in accordance with European safety regulations. This could cause serious injuries. If you have any doubts in relation to these essential safety requirements, consult local by-laws.



10. Keep all electronic appliances away from children or impaired persons. Do not allow them to handle these appliances without supervision.
11. Suitable for use enclosed spaces.
12. Make sure that the appliance is not connected to the power supply before taking apart the components of the ' lamp. Connect to the power supply only after the installation has been completed.
13. When you switch on the appliance, make sure that the lampshade is secure.
14. The fan is designed for use interior spaces. It is not suitable for installation in a bathroom or habitually humid areas. Please make sure that the lamp never comes into contact with water.
15. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with appliance. Cleaning and user maintenance shall not be made by children without supervisions.
16. The means for disconnection from the supply mains having a contact separation in all poles that provides full disconnection that must be incorporated in the fixed wiring in accordance with the wiring rules.



17. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

Description of symbol:

You will find all the symbols related to this lamp on both the product label and the box in which it came.

Insulation class II . This fan is double insulation and it must not be connected to the earth connection.

~ AC - Alternating current voltage

Hz Frequency (Hertz)

V voltage in volt

W Intensity of current in watts

 Exclusive use in enclosed spaces.

Level of protection against intrusion. You can find the corresponding protection level on the label of the lamp.

Characteristics of the appliance

Nominal voltage and
nominal frequency

220-240V~50-60Hz


Protection class



IP protection index

IP20


Nominal power






COMPONENT LIST

- Unpack your fan lamp carefully. Remove all parts and hardware.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the ceiling fan has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Examine all parts, you should have the following:




1	Wall plugs for screw x2	4	Fan lamp body x1
2	Mounting screws x4	5	Mounting bracket x1
3	Remote controller x1		



IFAN LAMP INSTALLATON

- The fan lamp must be installed in a location so that the fan lamp is spaced 300mm from the tip of the fan lamp to the nearest objects or walls.



- Remove the mounting bracket from the fan lamp canopy by loosening the screws. Use the mounting bracket as a template to mark the screw positions on the wall.
- Install the mounting bracket onto the wall by using appropriately sized mounting screws and anchors. Ensure the screws and anchors used are suitable for the mounting surface. (① & ②). Connect the mains supply wire to the terminal block. (③)

Main Supply Wire


Neutral – Blue
Live- Brown

Lighting Wire / Terminal block

Blue or N
Brown or L

Ensure the wires are secure and will not be exposed.

- Attach the canopy onto the mounting bracket and secure it by tightening the screws. (④)



ANGLED CEILING INSTALLATION

The hanging system of this fan is **ONLY** suitable for Flat ceiling installation.
DO NOT install the fan lamp on an angled ceiling.



USING THIS FAN LAMP

This fan lamp is controlled via the remote control.

2x AAA 1.5V(size) batteries are required to operate the remote control. Remove the battery cover from the back of the remote and insert 2 x AAA batteries. Ensure the polarities are correct as shown in the battery compartment.

OPERATING THE REMOTE:

Before you start using the remote, take the time to read through this section and get familiar with the buttons and function of each button.



Description of how the fan lamp works with the remote control unit

1. Light & Fan off

Press the button to turn OFF the light and fan

2. Fan deflector ON/OFF

Press the button to turn ON/OFF the Fan deflector.

3. The device has 6 different output levels.

Press these buttons to set fan running 6 different speeds.

Lamp color Temp

4. Fan off

5. Brightness 100% 6500K

6. Brightness 100% 3000K

7. Brightness 100% 4000K

8. Brightness regulator:

The adjustment takes place in stages. By pressing for a short period, it is possible to control the individual stages. Pressing the button permanently results in the maximum or minimum brightness being reached.

9. Light ON/OFF

Press the button to turn ON/OFF the light.


10. Setting Fan working time

Timer is 2H, 4H

CARE & CLEANING

NOTE: Always turn OFF the power at the mains switch before performing any maintenance or attempting to clean your fan lamp.

- Every 4 months periodic cleaning of your fan lamp is the only maintenance required. Use a soft brush or lint free cloth to avoid scratching the paint finish. Please turn off electricity power when you do so.
- Do not soak or immerse your fan lamp in the water or other liquids. It could damage the motor or create the possibility of an electrical shock.
- Ensure that the fan lamp does not come in contact with any organic solvents or cleaners. To clean the fan lamp, wipe with only a damp clean cloth with NO organic solvents or cleaners.
- The motor has a permanently lubricated ball bearing so there is no need to oil.




SAFETY PRECAUTIONS FOR BATTERY

- WARNING - Keep new and used batteries away from children.
- CAUTION - Do not ingest battery—Chemical burn hazard.
- Always use 2 x AAA battery type with this fan lamp remote controller.
- Ensure the batteries are inserted with the correct polarity.
- To prevent false operation during battery insertion or replacement, this fan lamp must be disconnected from the supply mains.

Remove batteries from the product when not in use for long periods of time.

- Batteries must be removed from the remote transmitter before it is discarded.
 - Dispose of exhausted batteries immediately and safely (so they cannot be retrieved by children). Batteries can still be dangerous. Contact your local council to safely dispose of the battery.
- Regularly check the product and make sure the battery box lid is correctly secured. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. If you suspect your child has swallowed or inserted a button battery, call the emergency number of your country if you are in Europe for fast, expert advice.

Battery Leaks: Battery contains chemicals and should be treated as any chemical would. Take precautions when handling leaked battery chemicals. Battery chemicals should not be placed near the eyes or ingested. call the emergency number of your country if you are in Europe for fast, expert advice.



LED

220-240V ~ , 50-60Hz
LED 33W



Motor 13W



Requires installation



Indoor use

When the time comes to eliminate this product, please consider the environmental impact and take it to recognised recycling facility instead of disposing it with general household waste. Take the equipment to a waste disposal site. Plastic and metal parts that are used in the construction of this appliance can be separated into pure grade which allow recycling. Ask to your service center for details. Everyone of us can participate on the environmental protection.

Athens - Greece/kivouri Keratea
ZAMBELIS LIGHTS
www.zambelislights.gr

